

SEE...

Cold Weather Reminders

Operators, cold weather can play havoc with your small emplacement excavator.

HERE ARE
A FEW POINTERS
TO KEEP IN MIND WHEN
THE TEMPERATURE
DROPS.

Alcohol Reservoir Full

Make sure the compressed air system antifreeze unit is ready for winter. The unit shoots ethyl alcohol into the air brake system to keep water from freezing in the brake lines.

Just eyeball the alcohol reservoir to make sure it's filled.

Set for Winter?

Make sure the automatic defrosting pump is set to the number 1 (open) position for winter.

Also, make sure the reservoir is filled—even in summer—so dirt and dust can't get in.


Rough Starting?

Your SEE may be hard to start when the temps drop below 32°F. That's why the cold weather starter system has a fuel canister that automatically injects ether into the engine when you push the cold start button.

If your excavator's engine starts rough after pushing the button, chances are the ether canister is empty. So, have your mechanic replace the canister.

Do **not** use spray-can ether to start the vehicle. Too much ether can damage pistons and connecting rods.

Alcohol reservoir full?



1 for winter
0 for summer

Replace canister when empty

